

Handleiding voor het programmeren handzenders

TE 666FU, TE 374 en TE 4402D

S.V.P Eerst lezen! Voordat u handelt

Vóór u begint, controleer eerst of u de volgende aansluitingen goed hebt aan gesloten.

Rood : is 12V accu (+), rechtstreeks op de accu monteren.

Zwart : is massa (-), carrosserie auto.

Roze : is 12V, via contact +.

Zwart/wit : moet op de deurschakelaar, mits de schakelaar massa geschakeld is. In ieder geval moet de zwart/witte draad massa maken, dit kunt u ook simuleren door de draad tegen massa te houden.

Als alles goed is aangesloten kunt u met de programmering beginnen.

U gaat in de auto zitten, laat de deur open, en steek de sleutel in het contact. Zet het contact 7 keer aan en uit, op de 7^e keer laat u de sleutel op contact staan en u zult zien dat de knipperlichten één keer knipperen, op dat moment houdt u de grote knop op de handzender 1 tot 2 seconden ingedrukt. Als de knipperlichten 6 keer knipperen is de programmering verricht. Is dit niet het geval dan moet u de procedure opnieuw uitvoeren.

Als de knipperlichten niet knipperen is er iets niet goed aangesloten.

Let met nadruk op de zwart/witte draad, deze moet massa maken anders kunt u het systeem niet programmeren!!!!

Manual for programming the transmitters

TE 666FU, TE 374 and TE 4402D

Please read this before acting!

Before you begin, check if you connected the following wires correctly.

Red : Power 12V (connect directly to the battery)

Black : Ground (automotive body)

Pink : Power 12V (ignition switch)

Black/White : Door switch (if it is connected to ground)

If not, press the wire to the automotive body

If all the wires are connected correctly, you can start the programming procedure:

- 1. Take a seat in the car and leave the door open, and put the key in the ignition switch.*
- 2. Switch the ignition on and off for 7 times and leave the ignition on at the seventh time and the flashing light will flash 1 time.*
- 3. When they do, press the big button on the transmitter for approximately 2 seconds.*
- 4. When the flashing lights flash 6 times, the system is programmed correctly.*
- 5. If the flashing lights do not flash, you have to repeat the procedure.*

If the flashing lights do not flash, there is something incorrectly connected!!

PAY ATTENTION! *If the black/white wire is not connected to Ground (automotive body), you can not program the system!!*